



Octave Fuzz

A dynamic octave fuzz that you can shape to meet your needs. Responsive to pick attack, the ability to roll off the octave with your guitar volume this pedal will do anything from a full-on thick octave fuzz to light clean overtures of octave fuzz to an almost ring mod like accent.



Layout and overview of the Octave Fuzz

Level: Controls the output level of the pedal.

Push: Will add more sustain and fuzz it essentially pushes the signal harder.

Palette: Controls the frequency or the octave in the circuit. This will create a brighter or a darker octave.

Attack: Controls the amount of signal that is being inserted into the octave side of the pedal.

On/Off: Located at the lower center of the pedal.

DC Power Jack: The pedal operates on a 2.1mm center negative regulated power supply at 9 volts DC. Do not try to power your pedal at a higher voltage.

Input/Output Jacks: The input is located on the right when looking down on the pedal and the output is located at the left.

The controls of the octave fuzz work together for the user to dial this pedal in to the exact type of octave fuzz they are looking for. Unlike most octave fuzz pedals this pedal gives the user the ability via the controls to mod the octave fuzz to their liking.

Always use a high quality and preferably regulated/isolated 2.1mm center negative power supply and cable can power your new pedal..

Use high quality electronics grade cleaners and lubricants for the occasional cleaning of pedal components. If you have any other questions or concerns please visit the FAQ page at www.wilsoneffects.com or email me at wilsoneffects@wilsoneffects.com. Your new pedal is covered by a one-year warranty on parts and labor. This warranty excludes friction-based components such as potentiometers and switches.