


ClydeSignature Wah

Thank you for purchasing a Wilson Effect's Clyde Signature Wah. Modeled after the infamous 1968 Clyde McCoy Signature Wah. The Signature Wah delivers the classic tone of the original with some updated features that will enable you to emulate the infamous wah tones heard throughout history.



Layout and overview of the Clyde Signature Wah

- A) Guitar Input
- B) LED On/Off Indicator
- C) Output to Amplifier (if available on model)
- **D) DC Power Jack:** Use only a 2.1mm center negative regulated power supply.
- E) Inside your pedal you will find a blue trimmer on the main circuit board. This trimmer allows you to set the input gain or level of the pedal. You can adjust this to your preference.

Either a 9v high quality alkaline battery or a 2.1mm center negative power supply and cable can power your new Clyde Signature Wah. When operating the pedal via battery you should unplug the pedal when not in use to insure the longest battery life. Try to keep your pedal as far away from your power supply as possible to minimize interference. Use high quality electronics grade cleaners and lubricants for the occasional cleaning of wah pedal components. If you have any other questions or concerns please visit the FAQ page at www.wilsoneffects.com or email me at wilsoneffects.com. Your new pedal is covered by a one-year warranty on parts and labor. This warranty excludes friction-based components such as potentiometers and switches.